



The Original Rigid Inflatable Cooler™

DEFLATION/PACKING INSTRUCTIONS



1. Make sure cooler is clean and completely dry before packing.



2. Assemble the pump by connecting the threaded end of the hose to the deflate port at the top of the pump handle.



3. Unscrew the grey cap at the side of the cooler; insure the inflation button is in the closed or out position; connect the pump hose to the valve by inserting the black gauge fitting and turning counter clockwise.



4. Begin deflation with the cooler lying on its base and pump until the cooler begins to compress and flatten.



5. Grasp the center and push down while squeezing the side walls together.



6. Completely flatten to push out any remaining air. Replace the grey valve cover cap.



7. Set cooler on end and fold in half so the blue rubber feet of the base touch.



8. Set cooler on the provided webbing strap with buckle.



9. Put one knee on the center of folded cooler and snap buckle. Pull on the webbing strap to tension.

Now just return cooler and pump to the mesh carry bag and enjoy all the space you saved.